





Locking and Unlocking Messages

- 1 From the Message-status screen, press ◀ or ▶ to select the message you want to lock/unlock.
- 2 Press ●.
- 3 Press ▶ to move the cursor to  lock or  unlock.
- 4 Press ●.

Deleting Messages



- 1 From the Message-status screen, press ◀ or ▶ to select the message you want to delete.
- 2 Press ●.
- 3 Press ▶ to move the cursor to .
- 4 Press ● to delete the message.


Setting the Time and Date

- 1 From the Function menu, press ◀ to move the cursor to .
- 2 Press ●.
- 3 Press ▶ to move the cursor to the hour digit.
- 4 Press ▲ or ▼ to adjust the hour.
- 5 Repeat steps 3 & 4 to adjust the minutes, AM/PM/24 hr., month, day & year.



- 6 Press ● to activate the setting.

Setting Alarms

- 1 From the Function Menu, press ◀ to move the cursor to .
- 2 Press ●.
- 3 Press ▼.
- 4 Press ▶ to move the cursor to the alarm symbol.
- 5 Press ▲ or ▼ until  is displayed.
- 6 Follow steps 3 through 6 in *Time and Date* to set the alarm time.


To disable the alarm, in step 5 above, press ▲ or ▼ until  is displayed.

To Set a Message Alarm




- 1 With the message displayed, press ●.
- 2 Press ▶ to move the cursor to .
- 3 Press ▲ or ▼ until  is displayed.
- 4 Follow steps 3 through 6 in *Setting the Time and Date*.

Note: To set a daily pager or message alarm, press ▼ until double dashes are displayed for the month, day, and year (--/--/--).


Storing Messages in Your Notebooks

- 1 From the Message-status screen, press ▲, ▼, ◀ or ▶ to move the cursor to the message you want to move into the notebook.
- 2 Press ●.
- 3 Press ▶ to move the cursor to .
- 4 Press ● to store the message.

Setting Auto on/off

- 1 From the Function menu, press ◀ to move the cursor to .
- 2 Press ●.
- 3 Press ▲ or ▼ to select  or .
- 4 Press ▶ to move the cursor to the hour digit.
- 5 Press ▲ or ▼ to adjust the hour.

Pager Symbols

- | | |
|---|--|
|  Power on |  Private Time enabled |
|  Audible Alert Mode on |  Alarm enabled |